



Shock and Floc Treatment.

Treatment for pools of 50m³ volume.

2 kg of Calcium Hypochlorite.

5.0 ltrs Fast Floc

5.0 kg of Sodium Bi-Carbonate.

- 1) Fill pool as much as possible. Will use water when vacuuming to waste.
- 2) Add chemicals to pool returns.
- 3) Run filter in by-pass or recirculate for 4 -6 hrs.
- 4) Allow pool to settle for 10 hrs, preferably overnight.
- 5) Vacuum to waste next morning.
- 6) Return filter to filter mode after vacuuming pool.
- 7) If pool water is discoloured repeat floc program and or check pH and Alkalinity.
- 8) Alkalinity 120 – 200 ppm
- 9) pH 7.2 – 7.8
- 10) Free Cl > 6ppm.
- 11) If any of 7 – 9 out of range adjust as necessary.

Any queries on the above please feel free to contact me.

Allistair Bliss.
Services Manager.